

NVC Managed Wireless Router Installation

1. Plug the included power adapter into an electrical outlet and then into your new router (#1). There will be an indicator light on the back of the router that will come on within 30 seconds.
2. Using the included white internet cable (or a cable you may already have in place), place one end into the slot that has a globe icon (#2) on the back of your new router and the other into the internet slot on your modem. (We have many different models of modems, so if you are unsure which is the internet slot, please give us a call).
3. If you have any devices you would like to hard-wire into the router, you can plug them into one of the two ports with the network icon (#3).
4. That's it! It will take approximately 3-5 minutes for your router to boot up then your internet and Wi-Fi should be good to go!



605-725-1000 nvc.net

